




Contents

Chapter 1: Read Before Use	1~5
Chapter 2: Product Summary	
2-1. System Configuration	6
2-2. How to Order	6~8
2-2-1. MONOSASHI-KUN	6
2-2-2. Applicable Auto-Switch Models	7
2-2-3. Options	7~8
2-3. Precautions on Selection	8
Chapter 3: Specifications	
3-1. Cylinder Specifications	9
3-2. Sensor Specifications	9
Chapter 4: Wiring	
4-1. Connector Wiring Table	10
4-2. Wiring for Counter	10
4-3. Noise countermeasures	10
Chapter 5: Structure and Measuring Principle	
5-1. Structure	11
5-2. Measuring Principle	12
5-3. Relationship Between Pulse and Count	12
Chapter 6: Troubleshooting	
6-1. Troubleshooting for Measuring Function	13, 14
6-2. Troubleshooting for Cylinder Operation	14
Data:	
Outside dimensions of CE1B12	15
Outside dimensions of CE1B20	16
Outside dimensions of CE1B32	17
Outside dimensions of CE1B40	18
Outside dimensions of CE1B50	19
Outside dimensions of CE1B63	20

Specifications are subject to change without prior notice.

Chapter 1: Read Before Use

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by label of “Caution”, “Warning” or “Danger”. To ensure safety, follow the below instructions as well as ISO4414^{*1)}, JIS B8370^{*2)} and other safety instructions.

 Caution	Operator error could result in injury or equipment damage.
 Warning	Operator error could result in serious injury or loss of life.
 Danger	In extreme conditions, there is a possible result of serious injury or loss of life.

* 1)ISO 4414 Pneumatic fluid power—Recommendations for the application of equipment to transmission and control systems.

* 2)JIS B8370 GENERAL RULES for PNEUMATIC SYSTEMS

Warning

1. The compatibility of pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or after analysis and/ or tests to meet your specific requirements. Ensuring the initial performance and safety are the responsibility of the person who decides the compatibility of pneumatic system. Pneumatic systems should be constructed after full review on the details of the products other than specifications and possibilities of failures by checking the latest product information.

2. Only trained personnel should operate pneumatically operated machinery and equipment.

Assembly, handling or repair of pneumatic systems should be performed by trained and experienced operators.

3. Do not service machinery/ equipment or attempt to remove component until safety is confirmed.

- a. Inspection and maintenance of machinery/ equipment should only be performed after confirmation of safe locked-out control positions.
- b. When equipment is to be removed, confirm the safety process as mentioned above. Cut the supply pressure for this equipment and exhaust all residual compressed air in the system.
- c. Before machinery/ equipment is re-started, take measures to prevent shooting-out of cylinder piston rod etc.

4. Contact SMC and take necessary safety measures if the products are to be used in any of the following conditions:

- a. Conditions and environments beyond the given specifications, or if products are used outdoors.
- b. Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverage, recreation equipment, emergency stop circuits, press applications, or safety equipment.
- c. An application which has the possibility of having negative effects on people, property, or animals, requiring special safety analysis.

Operating and Storage Environments

Warning

1. Environments to avoid

Avoid using or storing the products in the following environments which may cause failures. If the products need to be used or stored in those environments, take necessary measures.

- a. Place where ambient temperature exceeds the range of 0°C to 60°C.
- b. Place where ambient humidity exceeds the range of 25% to 85% RH.
- c. Place where condensation occurs due to sudden temperature change.
- d. Place where atmosphere containing corrosive gas, flammable gas or organic solvent.
- e. Place where atmosphere containing conductive powder such as dust and iron chips, oil mist, salt, or organic solvent, or splashing cutting chips, dust and cutting oil (water , liquid) over the products.
- f. Place where the products are exposed to direct sunlight or radiated heat.
- g. Place where strong electromagnetic noise is generated (place where strong electric field, strong magnetic field or surge is generated).
- h. Place where static electricity is discharged or condition that the products have electrostatic discharge.
- i. Place where strong high frequency is generated.
- j. Place where damages of thunder are expected.
- k. Place where vibration or impact is directly given to the products.
- l. Condition that the products are deformed by force or weight applied.

2. Do not close any objects which are affected by magnets.

Since magnets are built in cylinders, do not close magnetic disks, magnetic cards or magnetic tapes. The data may be destroyed.

Precautions on Design

Warning

1. There is a possibility of dangerous sudden action by cylinders if sliding parts of machinery are twisted due to external forces, etc.

In such cases, human injury may occur; e. g., by catching hands or feet in the machinery, or damage to the machinery itself may occur.

2. Provide a cover to minimize the risk of human injury.

When a driven object or moving parts of a cylinder may cause the risk of human injury, design a structure to avoid contact with human body.

3. Securely tighten all stationary parts and connected parts of cylinders so that they will not become loose.

Tighten cylinders securely especially when they are used in high frequency or in locations where direct vibration or impact shock, etc. will be applied to the body of the cylinder.

4. Deceleration circuits or shock absorbers are needed in some cases.

If a driven object travels at a high speed or is heavy, impact will not be sufficiently absorbed only with the cylinder cushion. In such cases, use a circuit to decelerate the cylinder speed before the cushion becomes effective or use external shock absorbers to reduce impact. At this time, take the rigidity of machinery into account.

5. Consider possible drop of pressure in circuit due to power outage.

For cylinders used in clamping mechanism, a work may become loose due to less clamping force by pressure drop in circuit at the time of power outage. Install safety devices to prevent human injury and machinery damage. Measures should be taken to prevent drop of hanging or lifting equipment.

6. Consider possible loss of power sources.

Measures should be taken to protect against human injury and machinery damage in the event that there is a loss of air pressure, electricity or hydraulic power.

7. Design circuit to prevent shooting out of a driven object.

A driven object is quickly shot out when pressure is supplied from one side of the piston after air in the cylinder is exhausted in such cases that cylinder is actuated by exhaust center type of directional control valve or started after residual air is exhausted from the circuit. At this time, human injury may occur; e.g., by catching hands or feet in the machinery, or damage to the machinery itself may occur. Therefore, the machine should be designed and constructed to prevent shooting out.

8. Consider emergency stops.

Design the machinery so that human injury and/or damage to machinery and equipment will not be caused when machinery is stopped by a safety device under abnormal conditions, a power outage or a manual emergency stop.

9. Consider actions when operation is restarted after an emergency stop or abnormal stop.

Design the machinery so that human injury or equipment damage will not occur upon restart of operation. When the cylinder is required to return to the initial position, provide the equipment with a safe override.

Selection

Warning

1. Confirm the specifications.

The product in this manual is designed to be used only in industrial compressed air system. The product should not be used with pressures or temperatures outside the range of the specifications, as this may cause damage or malfunction, etc.

2. Intermediate stop

When cylinder piston is stopped intermediately by 3-position closed center type of directional control valve, intermediate stop positions may not be as precise and exact as hydraulic operation due to compressibility of air. Valves and cylinders are not guaranteed for zero air leakage, and stop position may not be held in a long period of time. Consult SMC for long term holding of stop positions.

Caution

- 1. Mount speed controller and adjust cylinder operation speed gradually from low speed to a desired speed.**

Air Supply

Warning

- 1. Do not use the product out of the specified ranges for pressure and temperature to prevent equipment damage and mal-function.**

①Operating pressure:

Ø12 : 0.07 to 1.0 MPa

Ø20~Ø63 : 0.05 to 1.0 MPa

②Fluid & ambient temperature: 0 to 60°C

2. Use clean air.

Do not use the product with compressed air includes chemicals, synthetic materials (including organic solvents), salinity, corrosive gases, etc., as this may cause damage or malfunction.

Caution

1. Install air filter.

Install air filter before and in vicinity of valve. The filter should be able to collect particles of 5 microns or smaller. A large quantity of drain may cause malfunction of pneumatic components.

2. Install after cooler, air dryer, auto drain, etc.

Compressed air that includes excessive condensate may cause malfunction of valve and other pneumatic equipment. To prevent this, install after cooler, air dryer, auto drain, etc.

Installation


Warning

1. Do not give torque to the piston rod.

Giving torque to the piston rod may cause damage and malfunction.

When hardware and nuts are screwed into the piston rod end, the piston rod should be fully retracted.

Use double nuts to fix a work since MONOSASHI-KUN (Scale Reading Cylinder) does not have any parallel parts at the rod.



Please refer to the table of maximum torque

Ø12	10 Nm
Ø20, Ø32	20 Nm
Ø40, Ø50, Ø63	30 Nm

2. Ensure that the equipment operates properly before the use.

3. Operation manual

Do not install the products unless the safety instruction have been read and understood. Keep this operation manual on file for future reference.

Caution

1. Maintenance space

When installing the products, allow space for maintenance.

2. Installation of jigs

When hardware and nuts are screwed into the piston rod end, the piston rod should be fully retracted.

Use double nuts to fix a work since MONOSASHI-KUN (Scale Reading Cylinder) does not have any parallel parts at the rod.

3. Do not give strong impact and/or excessive moment when work is mounted.

External force other than allowable moment may cause rattle at guide part and/or increase in sliding resistance.

4. Use the product in such a condition that load is always applied in the axial direction of the piston rod.

When load is applied in other directions than cylinder axial direction, regulate the load itself by the guide.

Perform a complete centering when cylinder is mounted.

5. Avoid the use where torque is always applied to the piston rod or excessive impact acts on.

6. Do not give any damage and gouge on the sliding part of the piston rod.

Wiring

Warning

1. Preparation for wiring

Shut off the power before wiring (including insertion and removal of connectors). Mount a protective cover on the terminal block after wiring.

2. Check the power

Make sure the power has sufficient capacity and voltages are within the specified range before wiring.

3. Grounding

Ground terminal block F.G. (Frame Ground).

Do not ground it with devices generating strong electromagnetic noise.

4. Check wiring

Incorrect wiring may cause damage or malfunction of the products. Make sure the wiring is correct before operation.

Caution

1. Separation of signal wires from power wire.

Avoid common or parallel wiring of signal and power wires to prevent malfunction due to noise.

2. Wiring arrangement and fixation

Avoid bending cables sharply at connector part or electrical entry in wiring arrangement.

Inproper arrangement may cause disconnection which in turn causes malfunction. Fix cables close enough not to give excessive force to the connector.

Piping

Caution

1. Before piping

Remove cutting chips, cutting oil, dust, etc. in piping by flushing or cleaning before piping. Care should be taken especially that any cutting chips, cutting oil, dust, etc. do not exist after a filter.

2. At piping

① Foreign matter should not enter. Entering of foreign matter will cause malfunction.

② Cutting chips and sealing materials at piping threads should not enter valves when piping and fittings are screwed in. Leave 1.5 to 2 threads when seal tape is used.

Lubrication

Caution

1. Lubrication of cylinder

① This cylinder is pre-lubricated and can be used without lubrication.

② In case of lubrication, use a equivalent of the turbine oil type 1 ISO VG32. Once lubrication is performed, it should be continued since the initial lubricant flows out causing malfunction.

Sensor Unit

Caution

1. Do not remove the sensor unit.

The position and sensitivity of the sensor is adjusted properly. Removing or replacing the sensor may cause malfunction.

2. External magnetic field should be 14.5mT or less.

Strong magnetic field in the vicinity may cause malfunction since CEP1 sensor is magnetic type.

3. Do not pull sensor cable strongly.

Such action may cause failure.

4. Power supply line

Do not mount any switch or relay to power supply line (12 VDC to 24 VDC).

Maintenance and Check

Caution

1. Performing regular check

Check regularly that the products do not operate with failures unsolved. Check should be done by trained and experienced operators.

2. Dismantling of product and supply/exhaust of compressed air.

Before dismantling, ensure that drop preventing and runaway preventing treatments are properly provided, shut the power source of air supplied, and exhausts compressed air in the system. When starting operation again, operate the product with care after ensuring that a treatment for preventing extrusion is properly provided.

3. Prohibition of disassembly and modification

To prevent accidents such as failures and electric shocks, do not remove the cover to perform disassembly or modification. If the cover has to be removed, shut off the power before removal.

4. Disposal


Request a special agent for handling industrial waste to dispose the products.

Chapter 2: Product Summary

MONOSASHI-KUN is a cylinder that has a built-in linear encoder.


The scale of the magnetic rod and magnetic sensor detects change in piston position, and pulse signal is outputted with A/B quadrature pulse (90° nominal phase relationship). Position detection in 0.1 mm resolution is possible by inputting this signal to CEU1 (or CEU5).

2-1 System Configuration



2-2 How to Order

2-2-1 MONOSASHI-KUN



Standard cylinder stroke

Bore size (mm)	Stroke (mm)											
	25	50	75	100	125	150	175	200	250	300	400	500
12	○	○	○	○	○	○						
20	○	○	○	○	○	○	○	○				
32		○	○	○	○	○	○	○	○	○		
40				○	○	○	○	○	○	○	○	○
50								○		○		○
63								○		○		○


2-2-2 Applicable Auto-Switch Models

Mark	Auto-Switch Model	Mark	Auto-Switch Model	Mark	Auto-Switch Model			
A90	Reed Auto-Switch	D-A90	M9N	Solid State Auto-Switch	D-M9N	M9NW	2-color Indication Solid State Auto-Switch	D-M9NW
A93		D-A93	M9P		D-M9P	M9PW		D-M9PW
A96		D-A96	M9B		D-M9B	M9BW		D-M9BW
A90V		D-A90V	M9NV		D-M9NV	M9NWV		D-M9NWV
A93V		D-A93V	M9PV		D-M9PV	M9PWV		D-M9PWV
A96V		D-A96V	M9BV		D-M9BV	M9BWV		D-M9BWV
A72		D-A72	J79C		D-J79C	M9NA		D-M9NA
A72H		D-A72H				M9NAV		D-M9NAV
A73C		D-A73C				M9PA		D-M9PA
A80C		D-A80C				M9PAV		D-M9PAV
A79W	D-A79W			M9BA	D-M9BA			
				M9BAV	D-M9BAV			


See separate catalog for the details of Auto-switch.

2-2-3 Options

3-Point Preset Counter



Multi Counter



Extension Cable

CE 1 - R ※ ※

Cable Length	
O5	5m
10	10m
15	15m
20	20m

Connector *1	
Nil	Extension cable
C	Extension cable & connector

*1) Connector (Female) is mounted on one side of extension cable. Connector (Male) to be enclosed with the mark "C" is the same type as that mounted to standard CE1.

Extension Cable

CE1-R※※


*1) Connector (Female) is mounted on one side of extension cable. Connector (Male) to be enclosed with the mark "C" is the same type as that mounted to standard CE1.

Cable Length	
05	5m
10	10m
15	15m
20	20m

Connector *1	
Nil	Extension cable
C	Extension cable & connector

2-3 Precautions on Selection

- Use MONOSASHI-KUN CE1 with 3-Point Preset Counter CEU1 or Multi-Counter CEU5.
- For SMC CE1 series and SMC CEU1 series (or CEU5 series), operation check was performed with SMC extension cable CE1-R※※ for the maximum wire length of 23m. Since operation check was not performed with other counters and cables, a system designer who selects equipment should check the operation.
(See "Countermeasures for Noise" on page 10.)
- When CE1 with connector is used, extension cable CE1-R※ is necessary. For this extension cable, receptacle connector (female) for CE1 connector (male) is attached.
- When extension cable is connected to CE1 without connector, it is necessary to mount male connector on cylinder side. Use CE1-R※C extension cable. For connector with mark "C", one piece of cylinder side connector (male) is enclosed.
- CE1 without connector can be directly connected to terminal block of counter.



Chapter 3: Specifications

3-1 Cylinder Specifications

Action	Double acting, single rod (Non-rotating piston rod)		
Fluid	Air		
Proof pressure	1.5MPa		
Max. operating pressure	1.0MPa		
Min. operating pressure	$\phi 12$	$\phi 20 \sim \phi 63$	
	0.07MPa	0.1MPa	
Operating piston speed	70~500mm/s		
Ambient & fluid temperature	0~60° (No freezing)		
Humidity	25~85%RH (No dew condensation)		
Lubrication	Non-lube.		
Stroke tolerance range	$\phi 12 \sim \phi 20 : 0 \sim +1.0\text{mm}$	$\phi 32 \sim \phi 63 : 0 \sim +1.6\text{mm}$	
Cushion	$\phi 12 \sim \phi 32 : \text{None}$	$\phi 40 \sim \phi 63 : \text{Selectable}$	
Rod non-rotating accuracy	$\phi 12 : \pm 2^\circ$	$\phi 20 : \pm 1^\circ$	$\phi 32 \sim \phi 63 : \pm 0.8^\circ$
Mounting	Double end tapped (standard), Foot type, Flange type, Double clevis type		
Thread tolerance	JIS B0209		

3-2 Sensor Specifications

Cable	$\phi 7$, 6-core twisted pair shielding wire (Heat resistance, oil resistance, flameproof)
Maximum wire length	23m ^{*1}
Position detection method	Incremental encoder (rod with magnetic scale, magnetic sensor)
Magnetic field resistance	14.5mT
Power supply	12 VDC~24VDC ($\pm 10\%$) [Power ripple: 1% or less]
Current consumption	40mA
Resolution	0.1mm (at CEU1 or CEU5)
Accuracy(20°C)	$\pm 0.2\text{mm}$ ^{*2}
Output type	Open collector (Max. 24 VDC, 40 mA or less)
Output signal	A/B quadrature pulse (90° nominal phase relationship)
Insulation resistance	500 VDC, 50M Ω or more (Case: Between 12E)
Vibration proof	33.3 Hz, 66.7 m/s ² , two hours each in X and Y directions, four hours in Z direction, Conforming to JIS D1601
Impact resistance	294.2 m/s ² , three times each in X, Y and Z directions
Enclosure	IP—65 (IEC60529 standard) ^{*3}

* 1) When SMC cable and SMC CEU1 (or CEU5) counter are used.

* 2) Including error due to digital indication at Counter CEU1 (or CEU5).


The overall measurement accuracy after being mounted to the equipment may vary depending on the mounting state and environment. When accuracy of the equipment as a whole is required, calibration should be performed by the end users.

* 3) The cylinder section does not have a water resistant enclosure.

Chapter 4: Wiring

4-1 Connector Wiring Table

The table below shows combinations of contact mark and wire core color. The connector pin layout shows the layout of CE1 with connector.




Connector Pin Layout

Combinations of contact mark and core color

Contact Mark	Core Color	Signal
A	White	A-phase
B	Yellow	B-phase
C	Brown	COM(OV)
D	Blue	COM(OV)
E	Red	12~24 V
F	Black	0 V
G	—	Shield
H	—	—

4-2 Wiring for Counter



4-3 Noise countermeasures


Follow the instructions below to prevent malfunction due to noise.

1. Use SMC extension cable CE1-R** for wiring of MONOSASHI-KUN and CEU1 (CEU5).
 2. Keep signal wires away from the power cables in wiring.
 3. Mount a ferrite core to signal cables for possible radiated noise effects of cable.
 4. Use stable power source for CE1 power supply.
 5. Mount a noise filter for possible noise effects of power source.
- * For wiring, be sure to refer to "Operation manual of CEU1" with this operation manual.
 - * EMC Directive is satisfied by connecting the multi-counter (CEU5**-D).

Please refer to the operation manual of the multi-counter (CEU5) for details.

Chapter 5: Structure and Measuring Principle

5-1 Structure



- A part of the piston rod has scale (magnetic scale). In order to maintain the relative position of the scale and the sensor head, piston rod is used to have a structure of non-rotating cylinder.

⚠ Caution For the use of CE1, care should be taken for the followings due to the structural characteristics.

- **Do not give torque to the piston rod.**

Giving torque to the piston rod may cause sensor detection failure and cylinder malfunction.

- **Use the product in such a condition that load is always applied in the axial direction of the piston rod.**

Offset load may cause abrasion of bearing and packing. In addition, measuring accuracy may deteriorate.

- **Do not remove the sensor.**

The position and sensitivity of the sensor is adjusted properly. Removing or replacing the sensor may cause malfunction.

- **Do not pull sensor cable strongly.**

Such action may cause detection failure and other failures.


- **External magnetic field should be 145 gauss or less.**

Strong magnetic field in the vicinity may cause malfunction since CE1 sensor is magnetic type.

This is equivalent to a field in a radius of about 18 cm from a welding part using welding current of about 15000 amperes. When the product is used in stronger magnetic field, take some measures for shield by covering the sensor part with magnetic material.

5-2 Measuring Principle


MONOSASHI-KUN is an air cylinder that has a function to output piston stroke movement as pulse signal in 0.1 mm resolution. Measuring Principle is as follows.



- (1) Piston rod has scale consisting of magnetism layer and non-magnetism layer in 0.8 mm pitch.
- (2) Magnetic resistive element receives 2-phase signal(Signal①) of sin. and cos. by piston rod movement. For this waveform, 1 pitch (0.8 mm) is equal to one cycle.
- (3) This is amplified and divided into 1/8. As a result, 90° phase difference pulse signal (Signal②) is outputted, which is 0.1 mm per pulse.
- (4) By counting this pulse by counter, piston position can be detected in 0.1 mm resolution.

5-3 Relationship Between Pulse and Count

CE1 output is A/B quadrature pulse.



- ① In rod extending direction, A-phase turns on first, then B-phase turns on with the delay of approximately 90° phase difference.
- ② In rod retracting direction, B-phase turns on first, then A-phase turns on with the delay of approximately 90° phase difference. Counter performs addition in ① and does subtraction in ②. When addition in rod retracting direction is needed, switch wiring of A-phase with B-phase.

Chapter 6: Troubleshooting

6-1 Troubleshooting for Measuring Function


Failure	Cause	Countermeasure	Page of reference
Does not count.	Isn't the wiring removed, or is it correct?	Check the wiring and connector loosening.	10
	Is 12VDC or 24VDC supplied to the sensor?	Supply the rated power (12VDC-24VDC) to the sensor. Power other than the rated may cause failure.	10
	Is CEU1(CEU5) in count mode?	Count values are indicated only in the count mode. Press the MODE key to change to the count mode.	See the CEU1 CEU5 operation manual
	(When other counter is used) Counter setting is wrong.	If input mode switching is available with the counter, check the setting. Set the counter input to adding /subtraction mode, 2-phase input (90° phase difference input). CEU1,CEU5 are recommended.	See the operation manual of the counter.
	Short-circuit of the sensor due to entering of liquid or moisture.	Replacement of sensor unit is necessary if the circuit is corroded. In addition, take some countermeasures to prevent liquid or moisture from entering.	2
	Sensor output circuit will short-circuit if it is improperly wired and current larger than the rated is supplied.	If it failed, repair will be necessary. Consult SMC or the shop.	9,10
Measured value does not have reproducibility.	Counting speed of the counter is slow or it does not meet the requirements of the input waveform. (Depending on counter, counting speed may slow down due to pulse rise speed and duty conditions.)	CEU1,CEU5 are recommended. When a counter from other company is used, check the requirements on specifications.	12 and the operation manual of the counter.
	Wiring distance is too long and signal is attenuated. (When counter and cable from other companies are used, wiring distance of 23 m is not guaranteed.)	If the wiring is longer than 23m, provide transducer of differential input/output (option). CEU1,CEU5 are recommended.	9 and the operation manual of the counter.
	Is there any noise source such as large motor, AC type solenoid valve, relay, inverter power and others in the vicinity?	Take appropriate measures by referring to "Countermeasures for Noise".	10

Failure	Cause	Countermeasure	Page of reference
Measured value does not have reproducibility.	Isn't cylinder speed out of the specified range? When cylinder speed is too fast, counting error may occur. Knocking or bounding may also cause temporal high speed.	Cylinder speed should be in the range of 70 mm/s to 500 mm/s. In addition, prevent knocking and bounding.	9
	Is torque given to the piston rod? If the relative position of the sensor head and the scale is displaced, detection failure may be the result.	Do not give torque to the piston rod.	3,11


6-2 Troubleshooting for Cylinder Operation

Failure	Cause	Countermeasure	Page of reference
Cylinder does not operate.	Is air piping correct?	Check the piping. Perform it after thoroughly reading the precautions in Chapter 1.	3,4,11
	Isn't the orifice closed completely?	If the orifice is closed completely, open it gradually until it is adjusted properly.	3
	Is torque given to the piston rod?	Do not give torque to the piston rod. When operation returns to normal, repair will be required.	3,11
Knocking occurs.	Is cylinder speed within the specified range?	Cylinder speed should be in the range of 70 mm/s to 500 mm/s.	9
	When it is connected to the guide and other equipment, are they centered completely?	Perform centering completely for the connection of other equipment and jigs.	3,11
	Is torque given to the piston rod?	Do not give torque to the piston rod.	3,11
	Was lubrication once applied and stopped afterward?	Use the product without lubrication. Once lubrication is performed, it should be continued since the initial grease flows out.	4
	Is the cylinder splashed with solvents and chemicals? Solvents and chemicals may make grease flow out and affect packing.	Do not use in an environment where the product is splashed with solvents and chemicals.	2, 3


Outside dimensions of CE1B12




Outside dimensions of CE1B20




Outside dimensions of CE1B32



Outside dimensions of CE1B40



Outside dimensions of CE1B50



Outside dimensions of CE1B63

